


Installation Instruction


MT002 Cold Water Bidet

Components List




Installation Steps

1




Turn off the angle valve, and then flush out all the water in the tank

2




Remove the existing seat cover, and keep all the parts

3




- a. Without flexible pipe:
unscrew the pipe connector
- b. With flexible pipe:
take off the water supply pipe
and then place the flexible pipe
instead

4



Connect the hosepipe
to the adaptor

5




Connect the adaptor to
the water supply pipe

6




Connect the hosepipe to the bidet

7



Replace the existing
seat cover to the stool

8



Rotate the knob as illustrated,
turn on the angle valve and then
check if there is any seepage
and leakage for each joint

Specification

Model	MT002
Voltage	Non-electric
Water Supply Mode	Connect to the cold water supply pipe directly
Angle of Nozzle	Adjustable
Water Temperature for self-cleaning	Cold water
Self-cleaning	NO
Water Temperature	3°~ 35°
Room Temperature	3°~ 40°
Water Pressure	0.05 MPa ~0.6 MPa
Distance between Holes Axis	138 ~ 202 mm
Item Size	430x245x103mm

Trouble Shooting

Issues	Measures
The spray nozzle has no water	1.The water supply is cut off 2.The angle valve is closed 3.The spray nozzle is clogged 4. Low water pressure 5. Water supply pipe is bended
Low water pressure	1. The water flow control knob is adjusted to be low position 2. Water supply pipe is bended