






Ersatzteile / Spare parts

PM 1800 D

Handmixer
electric mixer

5907802901
0196

Skizze	Art.Nr.	Benennung	description
2	5907802011	Gehäuseabdeckung	rear cover
5	5907802012	Hitzebeständiges Pad	heat proof pad
6	5907802013	Kohlebürstenhalter (Satz = 2 Stück)	brush holder (set = 2 pieces)
7	5907802001	Kohlebürsten (Satz = 2 Stück)	carbon brush (set = 2 pieces)
8	5907802002	Kohlebürstenabdeckung	carbon brush cover
9	3908201101	Kabel	power cord
10	3908201102	Kabeltülle	sheath
13	5907802004	Kondensator	capacitor
14	5907802005	Schalter	switch
16	5907802006	Stator	stator
20	5907802007	Rotor	rotor
22 - 41 + 44-49 + 51-54 + 61-65	5907802008	Aufnahme mit Getriebe kpl.	gearing cpl.
43	5907802009	Drehzahlregler	speed control
50	5907802014	Gehäuse	house
59	5907802015	Griff unten	handle
70	5907802010	Drehgriff f. Gangschaltung	speed regulating knob
o.Abb.	5907802701	Mixer Einsatz (Satz = links+rechts)	mixer set (set= left+right)