



A104-850

Dimensions: 170 - 220, 75, 400, 80 - 280, 65 - 150, 50, 500 - 600, 800, L1 = (850), 0 - 200, 170 - 220, 75, 400, 80 - 280, 65 - 150, 50, 500 - 600, 800, L1 = (850), 0 - 200.

A104-1000

Dimensions: 170 - 220, 75, 400, 80 - 280, 65 - 150, 50, 500 - 600, 800, L1 = (1000), 0 - 200, 170 - 220, 75, 400, 80 - 280, 65 - 150, 50, 500 - 600, 800, L1 = (1000), 0 - 200.

A104-1200

Dimensions: 170 - 220, 75, 400, 80 - 280, 65 - 150, 50, 500 - 600, 800, L1 = (1170), 0 - 200, 170 - 220, 75, 400, 80 - 280, 65 - 150, 50, 500 - 600, 800, L1 = (1170), 0 - 200.

A104A

Dimensions: 170 - 220, 75, 400, 80 - 280, 65 - 150, 50, 500 - 600, 800, L1 = (1110), 0 - 200, 170 - 220, 75, 400, 80 - 280, 65 - 150, 50, 500 - 600, 800, L1 = (1110), 0 - 200.

Assembly Instructions:

1

A104

A104A

2

A104A

A104

