


ELECTRIC TOOL PARTS LIST

■ CORDLESS DRIVER DRILL
Model DS 18DBSL

2016·12·12
(E1)



PARTS

DS 18DBSL

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS	
*	1	370908	SEAL LOCK FLAT HD.SCREW (LEFT HAND) M6 X 20.5	1	
*	1	370909	SEAL LOCK FLAT HD.SCREW (LEFT HAND) M6 X 25	1	FOR EUROPE,RUS
*	2	335961	DRILL CHUCK 13VLRU-N (W/O CHUCK WRENCH)	1	
*	2	370897	DRILL CHUCK 13VLRB-Z (W/O CHUCK WRENCH)	1	FOR EUROPE,RUS
	3	370592	GEAR BOX ASS'Y	1	INCLUD.4-30
	4	370610	CLUTCH DIAL (A)	1	
	5	327146	CLICK SPRING	1	
	6	370602	NUT	1	
	7	370607	SPRING	1	
	8	370603	THRUST PLATE	1	
	9	370596	SPINDLE	1	
	10	370594	FRONT CASE	1	
	11	328717	WASHER (B)	1	
	12	370609	LOCK RING	1	
	13	319744	ROLLER	4	
	14	306936	STEEL BALL D5	6	
	15	370606	RING GEAR	1	
	16	370600	CARRIER	1	
	17	370616	PLANET GEAR (C) SET (5 PCS.)	5	
	18	331892	WASHER (A)	1	
	19	331895	SCREW SET D2 (2 PCS.)	2	
	20	370608	SHIFT ARM	1	
	21	370601	REAR CASE	1	
	22	324357	SCREW SET D3 X 12 (4 PCS.)	4	
	23	370605	SLIDE RING GEAR	1	
	24	370599	PINION (C)	1	
	25	370615	PLANET GEAR (B) SET (4 PCS.)	4	
	26	370598	PINION (B)	1	
	27	370614	PLANET GEAR (A) SET (4 PCS.)	4	
	28	370604	FIRST RING GEAR	1	
	29	339761	WASHER (B)	1	
	30	339762	MOTOR SPACER	1	
	31	361048	ROTOR PINION SET	1	
	32	370619	WIRING ASS'Y	1	INCLUD.38,42
	33	330583	SHIFT KNOB	1	
	34	313687	TAPPING SCREW (W/FLANGE) D3 X 16 (BLACK)	9	
	35		NAME PLATE	1	
	36	339768	PUSHING BUTTON	1	
	37	370618	HOUSING (A).(B) SET	1	
	38	370151	DC-SPEED CONTROL SWITCH	1	
	39	327001	TRUSS HD. SCREW M4 (BLACK)	1	
	40	332824	HOOK	1	
	41	327002	LOCK NUT M4 (BLACK)	2	
	42	339769	BATTERY TERMINAL	1	
	43	306952	STRAP (BLACK)	1	
*	44	335790	BATTERY BSL 1850 (EUROPE,AUS,NZL)	2	INCLUD.503
*	44	370739	BATTERY BSL 1850 (KOR)	2	INCLUD.503
*	44	339783	BATTERY BSL 1830C (EUROPE,AUS,NZL)	2	INCLUD.503
*	44	330068	BATTERY BSL 1830 (EUROPE,AUS,NZL)	2	INCLUD.503
*	44	334729	BATTERY BSL 1830 (TPE)	2	INCLUD.503

PARTS

DS 18DBSL

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS	
* 44	336690	BATTERY BSL 1830 (THA)	2	INCLUD.503	

STANDARD ACCESSORIES

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS	
* 501		CHARGER (MODEL UC 18YFSL)	1		
* 501		CHARGER (MODEL UC 18YSL3)	1		
* 501		CHARGER (MODEL UC 18YKSL)	1		
502	983006	+ DRIVER BIT NO.2 65L	1		
* 503	329897	BATTERY COVER	1		
* 504	337852	CASE	1		
* 504	337140	CASE	1	LARGE SIZE	
* 505	336471	CASE ASS'Y (STACKABLE 2)	1	INCLUD.506-508	
* 506	336472	LATCH	4		
* 507	336473	HANDLE	1		
* 508	336474	HINGE	2		
* 509	336475	INNER TRAY	1		

OPTIONAL ACCESSORIES

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS	
601	955657	- DRIVER BIT (A) 3MM X 70L	1		
602	955659	- DRIVER BIT (A) 4MM X 70L	1		
603	955674	- DRIVER BIT (A) 6MM X 70L	1		
604	983004	+ DRIVER BIT NO.1 65L	1		
605	983011	+ DRIVER BIT NO.3 65L	1		