


Číslo typu FS4300 ELEKTRONICKÝ ŠROUBOVÁK



Položka	Číslo dílu	Popis	Změn	Množstv	N/O	Možnost 1	Možnost 2	Poznámka
001	158875-2	doraz		1				
002	424163-2	prachovka		1				
003	424235-3	těsnění		1				
004	450881-6	fixovací kroužek		1	*			
004-1	455591-0	LOCK RING	O	1				
005	233974-2	pérová podložka=new234266-2		1				
006	232245-4	pružina		1				
007	266361-0	šroubek 4x30		3				
008	158882-5	GEAR HOUSING HSB COMPLETE		1				
009	232050-9	listová pružina		1				
010	216001-0	kulička 3,5		1				
011	158886-7	vřeteno		1				
014	234121-8	COMPRESSION SPRING 8		1				
015	267202-3	podložka 8 6823		2				
016	223170-0	ozubené kolo		1				
017	216008-6	kulička 4		3				
018	158884-1	převodovka cpl.		1				
019	216415-3	třecí podložka 6823 /20		1	*			
019-1	216415-3	třecí podložka 6823 /20	O	1				
020	216212-7	podložka 821		1				
021	424162-4	SEAL RING		1				
022	158874-4	GEAR HOUSING COVER COMPLETE		1				
023	451099-2	kroužek		1				
024	210007-0	kuličkové ložisko 608VV		1				
025	240083-0	větrák		1				
026	515759-1	rotor		1				
D10		INC. 23-25,27,28						
027	681636-0	izolační podložka = old 681667-9		1				
028	210062-2	ložisko MT952		1				
029	421868-5	kroužek 9554-9555		1				
030	266467-4	TAPPING SCREW 4X50		2				
031	450880-8	BAFFLE PLATE		1				
032	633693-4	stator		1				
033	450878-5	MOTOR HOUSING L		1				
034	162272-6	HOOK		1				
035	866576-5	FS4300 NAME PLATE		1				
036	808575-1	4000RPM INDICATION LABEL		1				
037	689111-0	guma držáku uhlíků HR2440		2				
038	191962-4	uhlíky CB-419 = CB-406,407		1				
039	643948-9	držák uhlíku		1				
040	643951-0	BRUSH HOLDER		1				
041	687124-5	držák kabelu		1				
042	650614-1	vypínač		1				
043	158878-6	držadlo		1				
C10	263002-9	vymešovací čep 4		2				
044	266374-1	šroub 4x25		1				
045	266374-1	šroub 4x25		2				
046	631939-2	LIGHT CIRCUIT		1				

vytisknout datum 22/05/2018