



Uživatelský návod pro

bezrámové pantové zástěny

Vitra Line

BN 3015 L

BN 4015 L

BN 4115 L

BN 4215 L


BN 4315 L




















Polysan s.r.o
Nesměřice 52
285 22 Zruč nad Sázavou


www.polysan.cz
www.polysan.net

e-mail: info@polysan.net

tel.: +420 327 585 983
fax.: +420 327 585 989





1  2x	13  1x	14  1x	
2  10x		15  2x	16  2x
3  10x			
4  4x			
5  4x	17  1x	18  1x	19  1x
6  4x			
7  1x			
8  1x	17  1x	18  1x	19  1x
9  1x			
10  1x			
11  1x			
12  2x	17  1x	18  1x	19  1x
Z  1x			







TYP	X	Y
BN 3015 L	1200± 6	-
BN 4015 L	1300± 6	-
BN 4115 L	1400± 6	-
BN 4215 L	1500± 6	-
BN 4315 L	1600± 6	-



A (1 : 1)




B (1 : 1)









L (1 : 1)




N (1 : 1)



P (1 : 1)



R (1 : 1)



S (1 : 1)

