



Uživatelský návod pro

bezrámové pantové zástěny

Vitra Line

BN 3315 L

BN 3415 L


BN 3515 L












Polysan s.r.o
Nesměřice 52
285 22 Zruč nad Sázavou



www.polysan.cz
www.polysan.net

e-mail: info@polysan.net


tel.: +420 327 585 983
fax.: +420 327 585 989











TYP	X	-
BN 3315 L	750	-
BN 3415 L	850	-
BN 3515 L	950	-







C (0,60 : 1)





D (0,60 : 1)



E (0,60 : 1)





F (1 : 1)

